


Powerwashing Chromebooks at Home

1. It doesn't matter at what state the Chromebook is, just hold the esc + refresh + power buttons down together for a few seconds



2. When the message comes up that the Chrome OS is missing or damaged, press the ctrl + d keys



3. Press the enter key 
4. Press the spacebar
5. Press the enter key again - WAIT while it reboots
6. The Chromebook will reboot - click on "let's go"
7. Choose your wi-fi network and enter the password (if at school: GSD Guest; Password: learning)
 - a. Click Connect
 - b. Click Continue
8. Remove the check from the Optional reports
9. Click on Accept and continue
10. Wait while the chromebook enrolls in enterprise edition (you will see a checkmark saying you are enrolled successfully)
11. Log in with **the student's** granitesd.org user account (4-4-4@granitesd.org)
12. Once successfully logged in, they can use their chromebook again.